

Mounting instructions / Руководство по техническому обслуживанию
EN

Before you start assembling the pump please check all the different parts are included.

These parts are:

- (1) Pump's body
- (2) Suction tube (3 pieces)
- (3) Crank
- (4) Drum adapter
- (5) Foot valve
- (6) Outlet spout

- Fit suction tube (2), as per the desired length, into pump's body (1) using sealant tape (8).
- Insert drum adapter (4) through suction tube (2).
- Fit foot valve (5) into suction tube (2) using sealant tape (8).
- Tighten crank (3) to pump's Body (1) using the bolt supplied.
- Thread the outlet spout (6) into the pump's body (1) using sealant tape (8).
- Once fully assembled, please fix it to the drum with the fitting (4).

Pump is now ready to be used. It is a self priming pump.

RU

Прежде чем вы начнете собирать насос пожалуйста проверите всели части входят в комплект

Комплект частей:

- (1) Корпус насоса
- (2) Всасывающая труба (3 части)
- (3) Ручка
- (4) Бочковой адаптер
- (5) Обратный клапан
- (6) Носик

- Установить всасывающую трубку (2) в корпус насоса (1) в соответствии с требуемой длиной.
- Вставьте адаптер для бочки (4) через всасывающую трубку (2).
- Установить обратный клапан (5) во всасывающую трубку (2).
- Ослабить рукоятку (3) корпуса насоса (1) с помощью прилагаемого болта.
- Проденьте выпускной носик (6) в корпус насоса (1)
- Полностью собранный, пожалуйста зафиксируйте к бочке штуцером (4).

Насос теперь готов к использованию. Насос самовсасывающий.

