Mi Sonic Hair Dryer User Manual 1
Фен Mi Sonic Hair Dryer: руководство пользователя 5
Benutzerhandbuch für den Mi Ionisator 9
Manuale utente del Mi Ionic Hair Dryer 13
Mi Sonic Hair Dryer - Manuel d'utilisation 17
Manual del usuario de Mi Ionic Hair Dryer 21
دليل المستخدم لمجفف الشعر المؤين Mi Sonic Hair Dryer 25

Precautions

To reduce the risk of malfunction, electric shock, injury, fire, death, and damage to property, make sure to observe the following safety precautions.

Symbol Description

Warning	Indicates the potential hazards that could result in serious injuries or death.
Note	Indicates the risk of minor injuries.

- Warning
  - Do not use if the certain operating steps must be followed in order to safely operate the product.

Warning

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.

Warning

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Do not use the appliance is used in a damaged manner. Do not pierce the proximity of water presence a hazard even when the appliance is switched off. Do not pierce, puncture, the installation of a residual current device (RCD) with a rated operating residual current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
- Children being supervised not to play with the appliance.
- The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Do not use the power cord or plug if it is damaged or if the socket-outlet is loose. Do not bend, twist, pull, or damage the power cord.
- Do not use the device if the plug is loose in the socket or if the plug or the socket-outlet is damaged, or if you feel a shock.
- Do not pinch, bend, twist, pull, or place heavy objects on, or squeeze the power cord. These actions may lead to electric shock or cause the due to a short circuit.
- Do not place the hair dryer on its air intake while turned on, as its heating coil may overheat and cause fire.
- Do not block or insert foreign objects into the air outlet and air intake, as this may cause burns, electric shock, or cause fire due to a short circuit.
- Do not damage the hair dryer in water.
- Do not use the hair dryer in environments with flammable gas.
- Keep the hair dryer dry, otherwise, it may result in electric shock or cause fire due to a short circuit.
- Do not use the hair dryer with wet hands, as this may result in electric shock or cause fire due to a short circuit.
- Do not place the hair dryer near petroleum gas or other flammable goods (such as volatile agents, paint products, etc.), or place it in a place where petroleum gas may flow, as this may cause fire.
- Do not leave the hair dryer when it is turned on, as this may cause fire. Unplug it when not in use.
- Do not wrap the power cord around the body of the hair dryer during storage. Doing so may result in the power cord becoming blue, electric shocks, or cause fire due to a short circuit.
- Do not place the hair dryer in a highly humid place, as this may result in electric shocks or cause fire due to a short circuit.
- Do not store the hair dryer within the reach of children, as this may result in electric shocks or cause fire.
- Do not use the hair dryer in water.
- Do not use the hair dryer for other purposes, or modify this product yourself, as this may cause injuries due to fire or electric shock.
- Do not use the appliance near flammable gas, liquids, beans or other sweating ceramic.

Warning

- Do not plug or unplug the power cord with wet hands, as this may result in electric shocks and injuries.
- Do not touch the power cord after the power switch of the appliance is used to prevent electric shock and injuries due to electric shock.
- Do not place the hair dryer in its air intake while turned on, as its heating coil may overheat and cause fire.
- Do not block or insert foreign objects into the air outlet and air intake, as this may cause burns, electric shock, or cause fire due to a short circuit.
- Do not damage the hair dryer in water.
- Do not use the hair dryer in environments with flammable gas.
- Keep the hair dryer dry, otherwise, it may result in electric shock or cause fire due to a short circuit.
- Do not use the hair dryer with wet hands, as this may result in electric shock or cause fire due to a short circuit.
- Do not place the hair dryer near petroleum gas or other flammable goods (such as volatile agents, paint products, etc.), or place it in a place where petroleum gas may flow, as this may cause fire.
- Do not leave the hair dryer when it is turned on, as this may cause fire. Unplug it when not in use.
- Do not wrap the power cord around the body of the hair dryer during storage. Doing so may result in the power cord becoming blue, electric shocks, or cause fire due to a short circuit.
- Do not place the hair dryer in a highly humid place, as this may result in electric shocks or cause fire due to a short circuit.
- Do not store the hair dryer within the reach of children, as this may result in electric shocks or cause fire.
- Do not use the hair dryer in water.
- Do not use the hair dryer for other purposes, or modify this product yourself, as this may cause injuries due to fire or electric shock.
- Do not use the appliance near flammable gas, liquids, beans or other sweating ceramic.

Warning

- Do not pull the power cord when unplugging the power plug. Make sure to hold the power plug when unplugging it. Pulling the power cord may damage it, or cause injuries, cause electric shocks, or cause fires due to a short circuit.
- Fully plug the power plug.
- Make sure your power supply is 220~240V~.
- Do not pour water, soda water, or other liquid onto, as this may result in electric shocks and cause fires due to a short circuit.
- To prevent safety hazards, the power cord needs to be replaced by the manufacturer.
- This product is not intended for use by persons with reduced physical, sensory or mental capacities, or lack the experience and knowledge (including children). When such persons use this product, a guardian must supervise or give them a guide and be responsible for the safety of the user. Otherwise, it may cause injuries or other accidents.

Note

- During use, the air output and air nozzle may get hot, so avoid contact with your hands, otherwise, this may cause burns or scalds.
- Avoid dropping the hair dryer or allowing it to be hit hard, as this may result in electric shocks or cause fires due to a short circuit.
- Do not use the hair dryer when the air intake is obstructed, otherwise, your hair or other objects may be sucked in and cause damage to the hair.
- Do not use the hair dryer on children, as this may cause injuries.
- Do not use the power cord when it is twisted. Otherwise, it may break, cause burns, electric shocks, or fire due to short circuit during future use.
- This product is only to be used by and help for Use. Do not use it on pets or its dry shoes, clothing, etc. Otherwise, it may cause burns or fires due to a short circuit.

Note

- During use, the air output and air nozzle may get hot, so avoid contact with your hands, otherwise, this may cause burns or scalds.
- Avoid dropping the hair dryer or allowing it to be hit hard, as this may result in electric shocks or cause fires due to a short circuit.
- Do not use the hair dryer when the air intake is obstructed, otherwise, your hair or other objects may be sucked in and cause damage to the hair.
- Do not use the hair dryer on children, as this may cause injuries.
- Do not use the power cord when it is twisted. Otherwise, it may break, cause burns, electric shocks, or fire due to short circuit during future use.
- This product is only to be used by and help for Use. Do not use it on pets or its dry shoes, clothing, etc. Otherwise, it may cause burns or fires due to a short circuit.

Note

- When using, please make sure that the distance between the hair dryer and your hair is at least 10 cm to avoid hair getting caught in the hair dryer.
- While using, please make sure that the distance between the hair and the air output is more than 3 cm to avoid hair damage.

Maintenance

- When cleaning, make sure that it is turned off and the power cord is unplugged.
- Please use a towel, cotton swab or toothbrush to remove dust from the air intake and air output regularly.
- To avoid damaging the product, do not pierce or rub your fingernails or sharp objects into the air intake or air output.
- Do not use the product if the air intake or air output is blocked or clean the product, as they may cause malfunction, cracking or falling.

This symbol indicates "Do not use while falling or drowning".

This symbol indicates "Do not use this appliance near bathtubs, showers basins or other vessels containing water".

Specifications

Name	Mi Ionic Hair Dryer
Model	CMJ01HD
Rated Voltage	220V~
Rated Frequency	50Hz
Rated Power	1600W
Net Weight	0.45kg
Dimensions (L*W*H)	180*77*235 mm (Excluding accessories)

Manufacturer: Hangzhou Xiaomi Electronics Technology Co., Ltd.
Address: 6th-8th Buildings, Science and Technology Park, No.9 Beisheng Road, Hangzhou Economic and Technological Development Zone, 310058 Hangzhou, China

Import Representative: Xiaomi Germany GmbH
Address: Theodor-Heuss-Allee 112, 60486 Frankfurt am Main, Germany

Import Representative: Xiaomi Technology France SAS
Address: 19 Place Vendôme, 75001 Paris, France

Import Representative: Xiaomi Technology Spain S.L.
Address: Calle Ribera del Loira, Nº 54, Planta 10, Oficina 1, 28042 Madrid, Spain

Import Representative: Xiaomi Technology Italy S.r.l.
Address: Via Cernaia 8/10, 20121 Milano, Italy

Import Representative: Xiaomi Technology Poland sp. z o.o.
Address: Ul. Puławska 405, 02-801 Warszawa, Poland

Import Representative: Xiaomi Technology Hungary Kft.
Address: Szépvölgyi út 35-37, 1037 Budapest, Hungary

Import Representative: Xiaomi Technology Romania S.R.L.
Address: Bucharest, Sector 1, Str. Av. Pierii nr. 1-3, Cladirea B, Birou 1, Etaj 1, Camera 1, Romania

Import Representative: Xiaomi Technology Czech s.r.o.
Address: Na Poříčí 1046/26, 110 00 Praha 1, Czech Republic

Import Representative: Xiaomi Technology Netherlands B.V.
Address: Zuidplein 36, 1077 XV Amsterdam, The Netherlands

Import Representative: Xiaomi Technology Portugal Unipessoal Lda.
Address: Rua Ribeiro Sanches, 65, 1200-787 Lisboa, Portugal

Import Representative: Xiaomi Technology Denmark A/S
Address: Amager Boulevard 70, 1. sal, 2300 København S, Denmark

Import Representative: Xiaomi Technology Sweden AB
Address: Box 191 03, 104 32 Stockholm, Sweden

Import Representative: Xiaomi Technology Ireland Limited
Address: 3rd Floor, Kilmore House, Park Lane, Spencer Dock, Dublin 1, D01 YE64, Ireland

Import Representative: Xiaomi Technology Finland Oy
Address: Kaivokatu 10 D, 00100 Helsinki, Finland

Import Representative: Xiaomi Technology Hellas Single Member S.A.
Address: 17 Ermou & Panagoulis, Syntagma, 105 63 Athens, Greece

Import Representative: Xiaomi Technology Croatia d.o.o.
Address: Ulica Grada Vukovara 271, 10000 Zagreb, Croatia

Import Representative: Xiaomi Technology Bulgaria EOOD
Address: 1 Slaviyanska Blvd., Sofia 1000, Bulgaria

Import Representative: Xiaomi Technology Slovakia s.r.o.
Address: Mlynské nivy 48, 821 09 Bratislava, Slovakia

Import Representative: Xiaomi Technology Slovenia d.o.o.
Address: Dunajska cesta 156, 1000 Ljubljana, Slovenia

Import Representative: Xiaomi Technology Estonia OÜ
Address: Tornimäe 5-5a, 10145 Tallinn, Estonia

Import Representative: Xiaomi Technology Latvia SIA
Address: Ģertrūdes iela 3, 1011 Rīga, Latvia

Import Representative: Xiaomi Technology Lithuania UAB
Address: Gynėjų g. 14, Vilnius, Lithuania

Import Representative: Xiaomi Technology Cyprus Limited
Address: Kyriakos Matsis Avenue 10, 2082 Strovolos, Nicosia, Cyprus

Import Representative: Xiaomi Technology Malta Limited
Address: Mercuriu Centre, Triq Dun Karm, Birkirkara, BKR 9033, Malta

Import Representative: Xiaomi Technology Luxembourg S.A.R.L.
Address: 2 Rue Edward Steichen, L-2540 Luxembourg

Import Representative: Xiaomi Technology Belgium BV
Address: Antwerpsesteenweg 19, 2800 Mechelen, Belgium

Import Representative: Xiaomi Technology Switzerland GmbH
Address: Bahnhofstrasse 21, 6300 Zug, Switzerland

Import Representative: Xiaomi Technology Norway AS
Address: Nedre Slottsgate 1, 0157 Oslo, Norway

Import Representative: Xiaomi Technology Iceland ehf.
Address: Ármúli 6, 108 Reykjavík, Iceland

Import Representative: Xiaomi Technology Turkey Limited Şirketi
Address: Cevizlibağ Mah. Turgut Özal Bulvarı No: 2/A Zeytinburnu/İstanbul, Turkey

Import Representative: Xiaomi Technology Middle East FZE
Address: Dubai Internet City, Building 1, Dubai, United Arab Emirates

Import Representative: Xiaomi Technology Thailand Co., Ltd.
Address: 1 Ploenchit Road, Lumpini, Pathumwan, Bangkok, Thailand, 10330

Import Representative: Xiaomi Technology Indonesia
Address: Jl. Boulevard Bintaro Jaya Blok A1 No. 1, Kel. Pondok Jaya, Kec. Pondok Aren, Kota Tangerang Selatan, Prov. Banten, Indonesia

Import Representative: Xiaomi Technology Malaysia Sdn. Bhd.
Address: Lot 2.07, Level 2, Menara Worldwide, No. 198, Jalan Bukit Bintang, 55100 Kuala Lumpur, Malaysia

Import Representative: Xiaomi Technology Philippines Inc.
Address: Unit 2306, Tower 1, The Enterprise Center, Paseo de Roxas, Makati City, Philippines

Import Representative: Xiaomi Technology Singapore Pte. Ltd.
Address: 1 Raffles Place, #20-61, One Raffles Place, Tower 1, Singapore 048616

Import Representative: Xiaomi Technology Japan G.K.
Address: Shinjuku Mitsui Building 2F, 2-1-1 Nishishinjuku, Shinjuku-ku, Tokyo, Japan

Import Representative: Xiaomi Technology Korea Yuhan-Hoesa
Address: 6F, 7F, 8F, 9F, 10F, 11F, 12F, 13F, 14F, 15F, 16F, 17F, 18F, 19F, 20F, 21F, 22F, 23F, 24F, 25F, 26F, 27F, 28F, 29F, 30F, 31F, 32F, 33F, 34F, 35F, 36F, 37F, 38F, 39F, 40F, 41F, 42F, 43F, 44F, 45F,