



\* ~127V  
 \*\* ~230V

**PRICE LIST OF SPARE PARTS**

Pos.	Part Number	Description (Q-ty)	Description National Language (Q-ty)	Price, USD
1	S-046	Inner hexagon screw M4x12 (2)		
2	M-129	Blade holder		
3	M-130	Wool cushion		
4	M-131	Sliding block (2)		
5**	E-005	Condenser 0.22µF 230V		
6	C-027	Switch		
7	L-070	Reciprocating bar		
8	P-027	Roller		
9	F-055	Gear		
10A	H-129	Housing A		
10B	H-130	Housing B		
11	S-009	Washer Ø6xØ14x0.2		
12	K-064	Bearing holder		
13	L-071	Positioning plate		
14	O-002	Ball bearing 608.RS		
15	S-046	Inner hexagon screw M4x14 (2)		
16*	1A-048	Armature 127V		
16**	A-048	Armature 230V		
17	J-031	Brush holder (2)		
18	J-032	Brush cover (2)		
19	D-013	Carbon brush (2)		
20	O-001	Ball bearing 607.RS		
21*	1B-042	Stator 127V		
21**	B-042	Stator 230V		
22	S-073	Screw ST4x12 (2)		
23	M-002	Cord clip		
24	S-075	Screw ST4x16 (9)		
25	N-126	Base		
26	S-207	"E" ring Ø4		
27	P-028	Roller for blade		
28	L-072	Pin for roller		
29	L-073	Roller support		
30*	1E-001	Cord 127V		
30**	E-001	Cord 230V		
31	M-062	Rubber sleeve		
32	P-029	Guard		
33*	1T-111	Brand label (2) 127V		
33**	T-111	Brand label (2) 230V		
500	Q-084	Breeze tube		
501	Q-085	Hex.key 3		