

Kit 1503


FORD Fiesta, 3-dr Hatchback, 08–

FORD Fiesta, 5-dr Hatchback, 08–



FORD Fiesta, 4-dr Sedan, *11–

FORD Fiesta, 5-dr Hatchback, *11–


***North America**



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



Max. 40 kg
Max. 88 lbs

THULE
Kit XXXX
instructions

x1

x4

754 Rapid System

x4

480R Rapid Traverse (North America)

x4

754 Rapid System
480R Rapid Traverse (North America)

x1

x4

x4

x4

480 Traverse (North America)

x2

x2
 23 mm

x2

x4

x4

x1
 17 mm

x2
 23 mm

x2

x2

x4

x4

(North America)

x2
 23 mm

x2

x2


410 **x4**

04 **x2**

65 **x2**

x1



1





2





754 Rapid System
480R Rapid Traverse
(North America)




x4





x4



x4




480 Traverse
(North America)




x4


3



754 Rapid System



	X
FORD Fiesta, 3-dr Hatchback, 08-	34
FORD Fiesta, 5-dr Hatchback, 08-	33
FORD Fiesta, 4-dr Sedan, *11-	34,5
FORD Fiesta, 5-dr Hatchback, *11-	34,5



	Y
FORD Fiesta, 3-dr Hatchback, 08-	29,5
FORD Fiesta, 5-dr Hatchback, 08-	30
FORD Fiesta, 4-dr Sedan, *11-	30
FORD Fiesta, 5-dr Hatchback, *11-	30

3




480R Rapid Traverse




480 Traverse



(North America)




	X inch	X mm
FORD Fiesta, 3-dr Hatchback, 08-	39 "	991 mm
FORD Fiesta, 5-dr Hatchback, 08-	39 "	981 mm
FORD Fiesta, 4-dr Sedan, *11-	39 1/4 "	997 mm
FORD Fiesta, 5-dr Hatchback, *11-	39 1/4 "	997 mm



	Y inch	Y mm
FORD Fiesta, 3-dr Hatchback, 08-	37 1/4 "	946 mm
FORD Fiesta, 5-dr Hatchback, 08-	37 1/2 "	951 mm
FORD Fiesta, 4-dr Sedan, *11-	37 1/2 "	953 mm
FORD Fiesta, 5-dr Hatchback, *11-	37 1/2 "	953 mm



4



FORD Fiesta, 3-dr Hatchback, 08-

5


SRA



FORD Fiesta, 5-dr Hatchback, 08-

FORD Fiesta, 4-dr Sedan, *11-








FORD Fiesta, 5-dr Hatchback, *11-





A

B


C





6




	X mm	Y mm	X inch	Y inch
FORD Fiesta, 3-dr Hatchback, 08–	250 mm	650 mm	9 ⁷ / ₈ ”	25 ⁵ / ₈ ”
FORD Fiesta, 5-dr Hatchback, 08–	320 mm	600 mm	12 ⁵ / ₈ ”	23 ⁵ / ₈ ”
FORD Fiesta, 4-dr Sedan, *11–	289 mm	610 mm	11 ³ / ₈ ”	24 ”
FORD Fiesta, 5-dr Hatchback, *11–	289 mm	610 mm	11 ³ / ₈ ”	24 ”



FORD Fiesta, 3-dr Hatchback, 08–



7



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apertar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно





CZ Pokrétla bagazníka dokręcaj dokręcaj naprzemiennie.
SK Doťahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egymástól függetlenül szorítandó
GR Σφιγγετε εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧



한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชั้้นในแบบสลับ




≈ 3 Nm




8





x1
17 mm





THULE
SWEDEN
**ONE
KEY
SYSTEM**



544 (x4)


596 (x6)

588 (x8)

NA **510** (x10)

EUR **452** (x12)

ASIA



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com
customer.service@thule.com

www.thule.com

503-1503-02