

# TORNADO 160

Code: 41210



## Elenco pezzi di ricambio / Liste pieces detachees Spare parts list / Ersatzteilliste Piezas de repuesto / Список запасных частей



| No | Desc  | Code      | pcs per box |
|----|---|-----------|-------------|
| 1  | Manopola / Knob / Drehknopf / Bouton / Manopola<br>Ручка регулятора тока  | M362100SP | 10          |
| 2  | Interruttore On-Off / On-Off Switch / Schalter On-Off<br>Interrupteur On-Off / Interruptor On-Off<br>Сетевой выключатель On-Off           | M485200SP | 20          |
| 3  | Pannello / Panel / Panneau / Verkleidung / Panel<br>Передняя панель   | S403500SP | 1           |
| 4  | Passacavo / Core hitch / Kabeldurchgang / Passecable /<br>Pasacable / Втулка  | M382000SP | 20          |
| 5  | Cordone di alimentazione / Power cord<br>Zufuehrungsschnur / Cordon d'alimentation / Cordon de<br>alimentacion / Электрический провод     | M581110SP | 5           |
| 6  | Piedino / Support / Unterstuetzung / Appui / Ayuda<br>Передняя опора  | S086600SP | 10          |
| 7  | Pinza massa / Earth clamp / Massenklemmplatte<br>Pince masse/ Зажим массы   | M612010SP | 2           |
| 8  | Pinza porta elettrodo / Electrode holder<br>Elektrodenhalter / Pincee porte electr / Pinza de<br>elect/ Держатель электрода               | M612610SP | 2           |
| 9  | Mantello / Mantle / Mantel / Cape / Capa / Копрыс   | S453500SP | 1           |
| 10 | Vetrino / Glass / Glas / Verre / Cristal / Стекло   | S084350SP | 20          |
| 11 | Coppiglia / Block wheel / Blockrad / Roue de bloc / Rueda<br>del bloque / Блокиратор колеса   | M908100SP | 20          |
| 12 | Assale / Axle / Axe / Achse / Eje / Ось   | M263285SP | 6           |
| 13 | Ruota posteriore fissa / Fix back wheelack wheel<br>Fixiertes Hinterrad / Roue postérieure fixe / Rueda<br>posterior fija / Заднее колесо | S075100SP | 10          |
| 14 | Maniglia / Handle / Handgriff / Poignée / Manija<br>Ручка   | S073400SP | 10          |




# TORNADO 160

Code: 41210




## Elenco pezzi di ricambio / Liste pieces detachees Spare parts list / Ersatzteilliste Piezas de repuesto / Список запасных частей



| No | Desc   | Code      | pcs per box |
|----|--|-----------|-------------|
| 15 | Termostato / Thermostat / Thermostat / Thermostate<br>Thermostato / Термостат  | M493500SP | 10          |
| 16 | Ventola / Roue à aubes / Impeller / Luefter<br>Impeledor / Вентилятор  | M500300SP | 4           |
| 17 | Trasformatore di potenza / Power transformer<br>Leistungstransformator / Transformateur de puissance<br>Transformador de potencia / Трансформатор мощности | S702150SP | 1           |
| 18 | Indice Shunt / Shunt index / Shuntindex / Index de shunt /<br>Указатель сварочного тока  | S053200SP | 20          |

### ACCESSORI / ACCESSORIES / ZUSATZGERÄTE


ACCESSOIRES / ACCESORIOS / ВСПОМОГАТЕЛЬНОЕ ОБОРУДОВАНИЕ



19



20



21



22

| No | Desc  | Code      | pcs per box |
|----|---|-----------|-------------|
| 19 | Spazzola / Brush / Bürste / Brosse / Cepillo / Щетка  | M830700SP | 2           |
| 20 | Maschera / Mask / Masque / Schablone / Máscara<br>Маска   | 90350SP   | 1           |
| 21 | Maniglia quadra / Square handle / Quadratischer<br>Handgriff / Poignée carrée / Manija cuadrada<br>Квадратная ручка | M261310SP | 6           |
| 22 | Tappo quadro / Square stopper / Quadratischer Stopper /<br>Taquet carré / Tapón cuadrado / Заглушка                 | S082200SP | 20          |