

# THOR 150

Code: 74100



## Elenco pezzi di ricambio / Liste pieces detachees Spare parts list / Ersatzteilliste Piezas de repuesto / Список запасных частей



From S/N:


No	Desc	Code	pcs per box
1	Amperometro / Ammeter / Ammetter / Ampèremètre Amperimetro / Амперметр	M423150SP	10
2	Pannello / Panel / Panneau / Verkleidung / Panel / Панель	S415150SP	1
3	Pinza rossa / Red clamp / Rote Klemmplatte / Bridge rouge / Abrazadera roja / Плюсовой зажим	M610650SP	2
4	Pinza nera / Black clamp / Schwarze Klemmplatte / Bride noire / Abrazadera negra / Минусовой зажим	M610600SP	2
5	Portafusibile / Fuse holder / Sicherung Halter / Support de fusibile / Sostenedor del fusibile / Держатель предохранителя	S061500SP	20
6	Fusibile / Fuse / Sicherung / Fusibile / Fusible Предохранитель	M495300SP	20
7	Interruttore On-Off / On-Off Switch / Schalter On-Off Interrupteur On-Off / Interruptor On-Off Переключатель режимов On-Off	M484500SP	20
8	Interruttore Min-Max / Min-Max Switch / Schalter Min-Max / Min-Max Interrupteur / Interruptor Min-Max Переключатель Мин-Макс	M484800SP	20
9	Mantello anteriore/ Front Mantle / Vorderer Umhang/ Manteau avant / Передняя часть корпуса	S465150SP	1
10	Mantello posteriore / Posterior Mantle / Hinterer Umhang / Manteau postérieur / Capa posterior Задняя часть корпуса	S365150SP	1
11	Maniglia / Handle / Handgriff / Poignée / Manija / Ручка	S070300SP	20

# THOR 150

Code: 74100



## Elenco pezzi di ricambio / Liste pieces detachees Spare parts list / Ersatzteilliste Piezas de repuesto / Список запасных частей



No	Desc	Code	
12	Ponte raddrizzatore / Rectifier bridge / Gleichrichter Pont redresseur / Puenet rectificador / Диодный мост	M781452SP	2
13	Trasformatore di potenza / Power transformer Leistungstransformator / Transformateur de puissance Transformador de potencia / Трансформатор мощности	M543150SP	1
14	Cordone di alimentazione / Power cord Zufuehrungsschnur / Cordon d'alimentation / Cordon de alimentacion / Электрический провод	M581110SP	5