

ELECTRIC TOOL PARTS LIST

■ CORDLESS LANTERN
Model UB 18DL

2004 • 9 • 20

(E1)



