


ENGINE




Ref	Part No.	Description	QTY	KIT
1	530 15 02-53	AIR FILTER	1	
2	530 01 61-01	NUT	1	
3	530 05 78-44	LEVER	1	
4	530 05 87-09	PRIMER BULB	1	
5	545 00 80-86	KIT-CARB. GASKET	1	7, 65
6	530 03 55-96	SPACER	1	
7	545 00 80-84	O-RING - FUEL CAP (KIT)	1	
8	530 01 64-00	BOLT	1	
9	952 03 02-01	SPARK PLUG	1	
10	545 00 80-84	O-RING - FUEL CAP (KIT)	1	
11	545 00 80-84	O-RING - FUEL CAP (KIT)	1	
12	503 87 33-05	STARTER PAWL BRIDGE	1	
13	530 09 56-46	FILTER	1	
14	530 06 95-99	HOSE	1	15
15	530 02 38-77	NIPPLE	1	

Ref	Part No.	Description	QTY	KIT
16	530 15 03-50	TANK CAP	1	17
17	545 00 80-84	O-RING - FUEL CAP (KIT)	1	
18	530 05 97-80	INSULATOR	1	
19	545 18 08-70	KIT-FUEL TANK ASSY.	1	13,14,15,16,17,18
20	576 15 32-01	SHROUD	1	
21	530 01 64-48	SCREW	1	
22	545 00 80-79	KIT-ROPE	1	
23	545 04 32-04	STARTER HANDLE	1	
24	530 01 64-26	SCREW	1	
25	530 01 64-49	SCREW	1	
26	576 38 21-01	KIT	1	
27	545 00 80-87	SPRING	1	
28	545 00 80-78	KIT-STARTER PULLEY	1	
29	544 03 88-02	SPRING	1	
30	544 03 87-02	DRIVER	1	
31	530 01 64-68	SCREW	1	
32	576 36 83-01	ASSEMBLY	1	22,23,25-31
33	530 05 89-82	BOLT	1	
34	530 01 52-41	SCREW	1	
35	530 15 04-40	PROTECTOR	1	
36	530 01 64-49	SCREW	1	
37	576 21 50-01	KIT	1	
38	545 03 05-01	SCREEN	1	34
39	574 03 15-02	KIT	1	33, 34, 38, 40
40	545 00 80-84	O-RING - FUEL CAP (KIT)	1	
41	530 01 58-97	SCREW	1	
42	545 04 67-01	IGNITION MODULE	1	
43	530 03 92-27	SHORTING LEAD	1	
44	530 01 64-56	SCREW	1	
45	530 01 64-63	WASHER	1	
46	530 09 41-89	WASHER	1	
47	545 17 34-01	BEARING - THRUST	1	
48	530 01 64-20	WASHER - THRUST	1	
49	530 01 58-05	SCREW	1	
50	530 01 57-74	SCREW	1	
51	530 01 57-68	NUT	1	
52	530 01 64-56	SCREW	1	
53	545 20 52-01	FAN HOUSING	1	
54	530 15 00-39	CLUTCH DRUM	1	
55	530 05 51-22	CLUTCH ASSY	1	
56	530 05 78-52	RING	1	
57	530 03 92-42	FLYWHEEL	1	
58	545 19 56-01	CRANKCASE-CAST	1	
59	545 01 34-01	BEARING	1	
60	545 19 52-02	ASSY-CRANKSHAFT	1	
61	530 01 51-62	CIRCLIP	1	
62	530 01 92-83	PISTON RING	1	
63	545 08 18-14	KIT	1	61, 62
64	545 00 80-83	KIT-PISTON/CYL.	1	63

Ref	Part No.	Description	QTY	KIT
65	545 00 80-84	O-RING - FUEL CAP (KIT)	1	
66	530 01 58-97	SCREW	1	
67	545 08 18-48	KIT - CARBURETOR	1	3, 4, 5
68	576 45 90-01	BASE	1	
69	530 05 78-46	COVER	1	
70	530 05 97-96	KNOB ASSY AIRBOX COVER	1	
71	545 00 80-84	O-RING - FUEL CAP (KIT)	1	5,7,10,11,17,40,65
72	576 49 63-01	KIT	1	


GEAR HOUSING



Ref	Part No.	Description	QTY	KIT
1	537 29 92-01	OIL PUMP ASSY	1	
2	740 42 03-00	O-RING	1	
3	503 23 00-16	WASHER STEEL	1	
4	503 18 49-01	SPRING	1	
5	503 23 00-16	WASHER STEEL	1	
6	503 80 83-02	PUMP PISTON	1	
7	725 53 27-55	SCREW IHSCM	1	
8	537 28 15-02	TANK CAP ASSY	1	
9	537 22 75-01	CAP	1	
10	537 04 03-01	VALVE	1	
11	503 98 13-01	PLUG	1	
12	725 53 29-55	SCREW IHSCM	1	
13	537 33 01-01	SEALING	1	
14	537 29 10-01	O-RING	1	
15	537 29 11-01	HOSE	1	
16	537 37 15-01	HOSE CLAMP	1	
17	504 71 00-03	OIL PLUMMET	1	
18	504 34 00-04	FITTING-PULSE INLET	1	

Ref	Part No.	Description	QTY	KIT
19	537 37 15-01	HOSE CLAMP	1	
20	537 29 09-01	CIRCLIP	1	
21	537 05 68-01	ADJUSTER	1	
22	503 97 82-01	SPRING	1	
23	537 33 17-01	OIL DUCT	1	
24	537 22 82-01	CHAIN TENSIONER	1	
25	537 19 42-01	CHAIN GUIDE PLATE	1	
26	738 21 00-04	BALL BEARING	1	
27	735 31 27-10	CIRCLIP	1	
28	735 31 12-00	E-CLIP	1	
29	537 32 92-01	SEALING	1	
30	537 19 44-01	BAR BOLT	1	
31	537 29 90-01	GEAR WHEEL KIT	1	
32	738 21 99-04	BALL BEARING	1	
33	725 53 33-55	SCREW IHSCM	1	
34	731 23 18-01	NUT	1	
35	537 24 60-01	COVER	1	
36	725 53 27-55	SCREW IHSCM	1	
37	537 22 74-01	HOUSING	1	
38	738 21 99-04	BALL BEARING	1	
39	537 24 77-01	SPACER	1	
40	738 21 99-04	BALL BEARING	1	
41	735 31 11-00	CIRCLIP	1	
42	735 31 25-10	CIRCLIP	1	
43	731 71 16-51	FLANGE NUT	1	
44	503 23 00-68	WASHER STEEL	1	
45	537 27 18-01	FLYWHEEL	1	
46	537 27 15-01	HUB	1	
47	537 27 17-01	RUBBER BUSHING	1	
48	537 27 14-01	RING	1	
49	537 27 16-01	CAP	1	
50	537 23 00-01	LABEL	1	

SHAFT & HANDLE



⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref	Part No.	Description	QTY	KIT
1	576 13 94-01	ASSEMBLY	1	
2	545 22 30-01	HOUSING RIGHT	1	
3	530 01 64-49	SCREW	1	
4	530 01 58-05	SCREW	1	
5	530 01 64-54	RETURN SPRING	1	
6	574 35 53-01	TRIGGER	1	
7	574 35 54-01	THROTTLE	1	
8	545 22 32-01	HOUSING LEFT	1	
9	545 04 93-09	SWITCH MOMENTARY	1	
10	545 11 33-01	WELT HOOK	1	
11	545 05 66-01	STAPLE	1	
12	530 01 59-40	SCREW	1	
13	725 23 80-51	SCREW EHHM	1	
14	503 87 90-01	KNOB	1	
15	545 14 43-03	ASSY - LOOP HANDLE	1	
16	503 94 03-01	DISTANCE.HANDLE	1	
17	502 19 71-01	NUT	1	
18	545 00 60-74	KIT DRIVESHAFT UPPER F/LDX	1	19

Ref	Part No.	Description	QTY	KIT
19	503 20 07-25	SCREW IHSCFM	1	
20	576 49 58-01	KIT	1	
21	537 24 71-01	CUTTING HEAD ASSY	1	
22	501 95 92-45	GUIDE BAR	1	
23	503 30 68-45	CHAIN	1	
24	537 21 62-02	HARNESS	1	