


## ENGINE




| Ref | Part No.     | Description             | QTY | KIT   |
|-----|--------------|-------------------------|-----|-------|
| 1   | 530 15 02-53 | AIR FILTER              | 1   |       |
| 2   | 530 01 61-01 | NUT                     | 1   |       |
| 3   | 530 05 78-44 | LEVER                   | 1   |       |
| 4   | 530 05 87-09 | PRIMER BULB             | 1   |       |
| 5   | 545 00 80-86 | KIT-CARB. GASKET        | 1   | 7, 65 |
| 6   | 530 03 55-96 | SPACER                  | 1   |       |
| 7   | 545 00 80-84 | O-RING - FUEL CAP (KIT) | 1   |       |
| 8   | 530 01 64-00 | BOLT                    | 1   |       |
| 9   | 952 03 02-01 | SPARK PLUG              | 1   |       |
| 10  | 545 00 80-84 | O-RING - FUEL CAP (KIT) | 1   |       |
| 11  | 545 00 80-84 | O-RING - FUEL CAP (KIT) | 1   |       |
| 12  | 503 87 33-05 | STARTER PAWL BRIDGE     | 1   |       |
| 13  | 530 09 56-46 | FILTER                  | 1   |       |
| 14  | 530 06 95-99 | HOSE                    | 1   | 15    |
| 15  | 530 02 38-77 | NIPPLE                  | 1   |       |

| Ref | Part No.     | Description             | QTY | KIT                    |
|-----|--------------|-------------------------|-----|------------------------|
| 16  | 530 15 03-50 | TANK CAP                | 1   | 17                     |
| 17  | 545 00 80-84 | O-RING - FUEL CAP (KIT) | 1   |                        |
| 18  | 530 05 97-80 | INSULATOR               | 1   |                        |
| 19  | 545 18 08-70 | KIT-FUEL TANK ASSY.     | 1   | 13, 14, 15, 16, 17, 18 |
| 20  | 576 38 21-01 | KIT                     | 1   |                        |
| 21  | 530 01 64-48 | SCREW                   | 1   |                        |
| 22  | 545 00 80-79 | KIT-ROPE                | 1   |                        |
| 23  | 545 04 32-05 | HANDLE                  | 1   |                        |
| 24  | 530 01 64-26 | SCREW                   | 1   |                        |
| 25  | 530 01 64-49 | SCREW                   | 1   |                        |
| 26  | 576 38 21-01 | KIT                     | 1   |                        |
| 27  | 545 00 80-87 | SPRING                  | 1   |                        |
| 28  | 545 00 80-78 | KIT-STARTER PULLEY      | 1   |                        |
| 29  | 544 03 88-02 | SPRING                  | 1   |                        |
| 30  | 544 03 87-02 | DRIVER                  | 1   |                        |
| 31  | 530 01 64-68 | SCREW                   | 1   |                        |
| 32  | 576 36 83-01 | ASSEMBLY                | 1   | 22, 23, 25-31          |
| 33  | 530 05 89-82 | BOLT                    | 1   |                        |
| 34  | 530 01 52-41 | SCREW                   | 1   |                        |
| 35  | 530 15 04-40 | PROTECTOR               | 1   |                        |
| 36  | 530 01 64-49 | SCREW                   | 1   |                        |
| 37  | 576 21 50-01 | KIT                     | 1   |                        |
| 38  | 545 03 05-01 | SCREEN                  | 1   | 34                     |
| 39  | 574 03 14-01 | KIT                     | 1   | 33, 34, 38, 40         |
| 40  | 545 00 80-84 | O-RING - FUEL CAP (KIT) | 1   |                        |
| 41  | 530 01 58-97 | SCREW                   | 1   |                        |
| 42  | 545 04 67-01 | IGNITION MODULE         | 1   |                        |
| 43  | 530 03 92-27 | SHORTING LEAD           | 1   |                        |
| 44  | 530 01 64-56 | SCREW                   | 1   |                        |
| 45  | 530 01 64-63 | WASHER                  | 1   |                        |
| 46  | 530 09 41-89 | WASHER                  | 1   |                        |
| 47  | 545 17 34-01 | BEARING - THRUST        | 1   |                        |
| 48  | 530 01 64-20 | WASHER - THRUST         | 1   |                        |
| 49  | 530 01 58-05 | SCREW                   | 1   |                        |
| 50  | 530 01 57-74 | SCREW                   | 1   |                        |
| 51  | 530 01 57-68 | NUT                     | 1   |                        |
| 52  | 530 01 64-56 | SCREW                   | 1   |                        |
| 53  | 545 20 52-01 | FAN HOUSING             | 1   |                        |
| 54  | 530 15 00-39 | CLUTCH DRUM             | 1   |                        |
| 55  | 530 05 51-22 | CLUTCH ASSY             | 1   |                        |
| 56  | 530 05 78-52 | RING                    | 1   |                        |
| 57  | 530 03 92-42 | FLYWHEEL                | 1   |                        |
| 58  | 545 19 56-01 | CRANKCASE-CAST          | 1   |                        |
| 59  | 545 01 34-01 | BEARING                 | 1   |                        |
| 60  | 545 19 52-02 | ASSY-CRANKSHAFT         | 1   |                        |
| 61  | 530 01 51-62 | CIRCLIP                 | 1   |                        |
| 62  | 530 01 92-83 | PISTON RING             | 1   |                        |
| 63  | 545 08 18-14 | KIT                     | 1   | 61, 62                 |
| 64  | 545 00 80-83 | KIT-PISTON/CYL.         | 1   | 63                     |

| Ref | Part No.     | Description             | QTY | KIT     |
|-----|--------------|-------------------------|-----|---------|
| 65  | 545 00 80-84 | O-RING - FUEL CAP (KIT) | 1   |         |
| 66  | 530 01 58-97 | SCREW                   | 1   |         |
| 67  | 545 08 18-47 | KIT - CARBURETOR        | 1   | 3, 4, 5 |
| 68  | 576 45 90-01 | BASE                    | 1   |         |
| 69  | 530 05 78-46 | COVER                   | 1   |         |
| 70  | 530 05 97-96 | KNOB ASSY AIRBOX COVER  | 1   |         |
| 71  | 545 00 80-84 | O-RING - FUEL CAP (KIT) | 1   |         |
| 72  | 545 00 33-53 | KIT-DECAL               | 1   |         |

## SHAFT & HANDLE



| Ref | Part No.     | Description      | QTY | KIT            |
|-----|--------------|------------------|-----|----------------|
| 1   | 576 13 94-01 | ASSEMBLY         | 1   |                |
| 2   | 545 22 30-01 | HOUSING RIGHT    | 1   |                |
| 3   | 530 01 64-49 | SCREW            | 1   |                |
| 4   | 530 01 58-05 | SCREW            | 1   |                |
| 5   | 530 01 64-54 | RETURN SPRING    | 1   |                |
| 6   | 574 35 53-01 | TRIGGER          | 1   |                |
| 7   | 574 35 54-01 | THROTTLE         | 1   |                |
| 8   | 545 22 32-01 | HOUSING LEFT     | 1   |                |
| 9   | 545 04 93-09 | SWITCH MOMENTARY | 1   |                |
| 10  | 530 01 58-20 | SCREW            | 1   |                |
| 11  | 545 13 97-01 | HANDLE           | 1   |                |
| 12  | 545 11 33-01 | WELT HOOK        | 1   |                |
| 13  | 545 05 66-01 | STAPLE           | 1   |                |
| 14  | 530 01 59-40 | SCREW            | 1   |                |
| 15  | 530 05 91-85 | CLAMP            | 1   |                |
| 16  | 530 01 61-52 | WING NUT         | 1   |                |
| 17  | 575 77 61-01 | KIT              | 1   | 27, 28, 31, 33 |
| 18  | 545 00 75-07 | SHAFT            | 1   |                |

| Ref | Part No.     | Description    | QTY | KIT        |
|-----|--------------|----------------|-----|------------|
| 19  | 537 21 62-01 | HARNESS        | 1   |            |
| 20  | 545 03 09-01 | PROTECTOR      | 1   | 21, 22, 30 |
| 21  | 530 05 22-86 | BLADE          | 1   |            |
| 22  | 530 01 58-14 | SCREW          | 1   |            |
| 23  | 504 00 13-03 | GRASS BLADE    | 1   |            |
| 24  | 503 89 01-01 | SUPPORT CUP    | 1   |            |
| 25  | 537 28 56-01 | SUPPORT FLANGE | 1   |            |
| 26  | 503 85 63-01 | NUT BLADE      | 1   |            |
| 27  | 530 01 60-14 | SCREW          | 1   |            |
| 28  | 545 00 39-02 | SCREW          | 1   |            |
| 29  | 537 23 49-01 | DRIVER ASSY    | 1   |            |
| 30  | 530 01 57-71 | SCREW          | 1   |            |
| 31  | 530 05 75-54 | BRACKET        | 1   |            |
| 32  | 502 28 59-01 | STOP           | 1   |            |
| 33  | 530 09 62-95 | BEVEL GEAR     | 1   |            |
| 34  | 537 33 83-06 | TRIMMER HEAD   | 1   |            |