

SPARE PARTS LIST

MODEL NO. JS1600

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	911156-3	PAN HEAD SCREW M4X30	4	
002	157477-1	GEAR HOUSING	1	
003	*****	*****	***	*****
004	253823-7	FLAT WASHER 7	1	
005	331151-1	ROD	1	
006	212063-6	NEEDLE BEARING 1012	1	
007	253758-2	FLAT WASHER 10	1	
008	153138-1	CRANK SHAFT COMPLETE	1	
009	253715-0	FLAT WASHER 6	1	
010	156731-0	GEAR HOUSING COVER	1	
		INC. 19		
011	211033-2	BALL BEARING 608LB	1	
012	241081-7	FAN 58	1	
013	511433-9	ARMATURE ASS'Y 220V	1	
		INC. 11,12,14,15		
014	681614-0	INSULATION WASHER	1	
015	211028-5	BALL BEARING 627LB	1	
016	*****	*****	***	*****
017	263002-9	RUBBER PIN 4	1	
018	*****	*****	***	*****
019	263002-9	RUBBER PIN 4	1	
020	256110-3	PIN 6	1	
021	913427-4	SET SCREW M8X16	1	
022	341676-7	PROTECTOR	1	
023	942101-7	SPRING WASHER 5	1	
024	*****	*****	***	*****
025	321311-3	BLADE HOLDER	1	
026	253334-2	THIN WASHER 5	2	
027	922112-8	HEX. SOCKET HEAD BOLT M4X10	1	
028	922127-5	HEX. SOCKET HEAD BOLT M4X16	1	
029	311717-3	YOKE	1	
031	251986-3	H.S.SET SCREW(FLAT POINT)M6X6	1	
032	911158-9	PAN HEAD SCREW M4X30	2	
033	411981-7	SWITCH COVER	1	
034	911133-5	PAN HEAD SCREW M4X18	2	
035	687031-2	STRAIN RELIEF	1	
036	643550-8	BRUSH HOLDER CAP 5-8	2	
037	191628-6	CARBON BRUSH CB-65	1	
038	651821-9	SWITCH ZGM-54	1	
040	815652-2	NAME PLATE JS1600	1	
041	157720-8	MOTOR HOUSING	1	
		INC. 17		
042	682521-0	CORD GUARD 10	1	
043	*****	*****	***	*****
044	665852-2	POWER SUPPLY CORD 1.0-2-2.0	1	
046	961017-7	STOP RING E-3	1	
047	341858-1	SWITCH LEVER	1	
048	256626-8	PIN 4	1	
400	410048-8	WRENCH HOLDER 3.4	1	
401	783201-2	HEX. WRENCH 3	1	
402	191383-0	SHEAR BLADE SET	1	
900	231322-9	COMPRESSION SPRING 3	1	
901	341930-9	LOCK LEVER	1	

SERVICE DRAWING

MODEL NO. JS1600

