

SPARE PARTS LIST

MODEL NO. BST110

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	266130-9	TAPPING SCREW BIND PT 3X16	1	
002	267071-2	FLAT WASHER 4	1	
003	188467-3	HOUSING SET INC. 79	1	
004	643811-6	TERMINAL	1	
005	324705-1	HOOK	1	
006	251314-2	+ SCREW M4X12	1	
007	266130-9	TAPPING SCREW BIND PT 3X16	4	
008	419450-2	FRONT COVER	1	
009	266130-9	TAPPING SCREW BIND PT 3X16	1	
010	345704-0	UPPER PLATE	1	
011	345703-2	RAIL	1	
012	324683-5	GUIDE BOLT	1	
013	253762-1	FLAT WASHER 8	1	
014	421962-3	SPRING HOLDER	1	
015	234035-1	COMPRESSION SPRING 16	1	
017	345865-6	HAMMER	1	
018	424059-7	CUSHION	1	
019	253804-1	FLAT WASHER 6	1	
020	266130-9	TAPPING SCREW BIND PT 3X16	1	
021	318025-3	HOLDER	1	
022	931302-2	HEX. NUT M6	1	
023	345864-8	TRIGGER PLATE	1	
024	345857-5	DRIVER	1	
025	268189-2	PIN 4	1	
026	922122-5	HEX.SOCKET HEAD BOLT M4X14	2	
027	922122-5	HEX.SOCKET HEAD BOLT M4X14	2	
028	158417-2	DRIVER GUIDE COMPLETE	1	
029	345863-0	SPACER	1	
030	345862-2	SPACER PLATE	1	
031	345860-6	SET PLATE	1	
032	158661-1	MAIN MAGAZINE COMPLETE	1	
033	450224-2	END CAP	1	
034	911113-1	PAN HEAD SCREW M4X10	1	
035	345858-3	PUSHER	1	
036	165479-3	SUB MAGAZINE	1	
037	450225-0	FOOT	1	
038	265127-5	+ PAN HEAD SCREW M4X4	1	
039	268029-4	PIN 4	1	
040	421637-4	MAGAZINE END	1	
041	233519-6	TORSION SPRING 5	1	
042	345861-4	LEVER	1	
043	961017-7	STOP RING E-3	1	
044	234036-9	COMPRESSION SPRING 5	1	
045	324836-6	ROD	1	
046	629848-7	DC MOTOR	1	
047	267053-4	FLAT WASHER 12	1	
048	227166-3	INTERNAL GEAR 69	1	
049	232230-7	LEAF SPRING	2	
050	221961-3	SPUR GEAR 27	3	
051	154973-0	SPUR GEAR 7 COMPLETE	1	
052	345773-1	ANTI BACK PLATE	1	
053	158418-0	SPUR GEAR 55 COMPLETE	1	
054	214060-8	PLANE BEARING 10	1	
055	651891-8	SWITCH V-15-3A6	2	
056	256299-7	PIN 3	1	
057	419453-6	LINK PLATE	1	
058	231693-4	TORSION SPRING 4	1	
059	419454-4	SAFETY TRIGGER	1	
060	256299-7	PIN 3	1	
061	188168-3	TRIGGER SET	1	

SPARE PARTS LIST

MODEL NO. BST110

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
		INC. 62-67		
062	419451-0	TRIGGER	1	
063	256771-9	PIN 2.5	1	
064	257926-9	STOP RING E-2.0	2	
065	345707-4	SWING ARM	1	
066	231694-2	TORSION SPRING 3	1	
067	231695-0	TORSION SPRING 3	1	
068	234037-7	COMPRESSION SPRING 5	1	
069	256176-3	PIN 2.5	1	
070	256176-3	PIN 2.5	1	
071	345706-6	GUIDE PLATE	1	
072	231692-6	TORSION SPRING 4	1	
073	*****	*****	***	*****
074	233188-3	COMPRESSION SPRING 2.4	1	
075	951001-0	SPRING PIN 2-8	1	
076	*****	*****	***	*****
077	345708-2	SWITCH ARM	1	
078	256176-3	PIN 2.5	1	
079	188467-3	HOUSING SET INC. 3	1	
080	864861-0	BST110 NAME PLATE	1	
081	911163-6	PAN HEAD SCREW M4X35	1	
082	266130-9	TAPPING SCREW BIND PT 3X16	8	
083	911113-1	PAN HEAD SCREW M4X10	2	
A01	*****	*****	***	*****
A02	*****	*****	***	*****
A03	806833-9	BST110RFE PLASTIC CASE LABEL	1	
A04	*****	*****	***	*****
A05	***DC18RA	DC18RA FAST CHARGER	1	
A06	450128-8	BATTERY COVER	1	

SERVICE DRAWING

MODEL NO. BST110

